



**CRETE  
CLEAN**<sup>PLUS</sup>  
WITH SCAR GUARD™

**SINGLE  
DOSE**

FOR AUTO SCRUBBER

# FLOOR CARE DIRECTIONS

## AUTO SCRUBBER DILUTION RATIO

**1 Bottle**

(12 oz / 0.35 L)

CreteClean Plus with Scar Guard  
SINGLE DOSE

**20-30 gal**

(76 - 114 L)

Fresh Water

Cleaning Surface Area **500 ft<sup>2</sup>/gal**  
12.3 m<sup>2</sup>/L

## TECHNICAL ASSISTANCE

Technical Help:

**(844) 644-4304**

**+1 (801) 515-6219**

cretecleantechnical@curecrete.com

Emergency:

**(800) 633-8253**

**+1 (801) 629-0667**

*Frequency of floor cleaning is based on the soilage of the floor.  
Minimum requirement to maintain your floor's Lifetime Warranty is 3 times per week.*

### 1 SWEEP THE FLOOR

Sweep the floor to remove all loose soil and debris using a dry/dust mop (preferably synthetic). *Note: It is best to sweep the floor with a dry/dust mop, as it holds grit and fine particles and takes them off the floor.*

### 2 FILL AUTO SCRUBBING MACHINE WITH CLEANING SOLUTION

Shake well and add the entire contents of 1 - 12 oz. bottle (0.35 L) into an auto scrubber tank filled with 20-30 gallons (76-114 L) of fresh water. *Note: This dilution ratio applies specifically to an empty auto scrubber tank.*

### 3 MOVE MACHINE TO AREA THAT NEEDS CLEANING AND AFFIX PADS/BRUSHES

Move the scrubbing machine to the area that needs cleaning. Plan the most appropriate scrub path for the floor. Affix pads/brushes to the scrubbing machine. *Note: Different color pads/brushes can be used for more aggressive cleaning.*

### 4 TURN ON SOLUTION VALVE TO MAXIMUM FLOW

Turn on the solution valve to maximum flow. Allow water to commence dripping off the pads/brushes before lowering pad heads/brushes to floor (this will avoid causing donuts on the floor surface). Lower pads/brushes and turn on.

### 5 TURN ON VACUUM AND ADJUST WATER FLOW

Turn on vacuum, lower squeegee and commence scrub pattern. *Note: This step can be delayed if you are double scrubbing an area (see step 6).* Adjust water flow when machine is moving to avoid flooding and splash.

### 6 DOUBLE SCRUB (IF NECESSARY)

When a double scrub is required, leave squeegee up and scrub floor without picking up solution on the first pass. Turn and scrub over the same path again with the squeegee lowered to pick up the soiled solution.

### 7 DISPOSAL OF SOILED SOLUTION

Dispose of the soiled solution according to your local government regulations.